



EMERGENCY ROOF REPAIR

**STOPS SUDDEN &
UNFORESEEN LEAKS
IN ROOF FELT AND GUTTERS**

Marley Waterproofing Emergency Roof Repair has been specially formulated to stop leaks in roofs and gutters in emergency situations, even under the most severe weather conditions.

Marley Waterproofing Emergency Roof Repair helps prevent sudden and unforeseen leaks from causing extensive damage to your home, enabling more time for a permanent repair to be planned.



Directions for Use

Surface Preparation: First locate the leak – leaks are usually located around chimneys, drainage channels, rooflights, near blisters and/or tears in the roofing material and around open joints and loose wall flashings. Remove all loose deposits on the surface such as dirt, leaves, snow, excess water using a stiff brush.

Application: Immediately apply Marley Waterproofing Emergency Roof Repair to the problem area using a filling knife or trowel and press firmly. Leave Marley Waterproofing Emergency Roof Repair exposed to the elements, so that the curing process can take place satisfactorily. Once weather conditions improve, it is recommended that the problem area is treated with one of Marley Waterproofing's quality waterproofing membranes or roof repair products to provide further long term protection.

Important Note: Should it become apparent that the leaks in your roof are attributable to either ageing or design faults in the existing roofing material, it is advisable to inspect the surface thoroughly in more clement, dry weather so that permanent repairs can be carried out. If in doubt, seek professional advice.

Cleaning: Tools can be cleaned with white spirit.

Storage: Containers should be kept sealed in a cool, dry, well ventilated environment and all practical precautions taken against fire. Partly used containers may be resealed and used again after correct storage. Always store and transport in a secure upright position.

Safe Handling: Keep away from sources of ignition, including pilot lights and sparks - No smoking. In case of fire use foam, dry powder or CO₂ extinguisher, sand or earth. Never use water. Avoid contact with skin by careful working and use of gloves. In case of contact with skin wash immediately with soap or a recognised skin cleanser. Do not use solvents to clean the skin. Use only in well ventilated areas. When using, do not eat, drink or smoke. A safety data sheet is available on request.

Disposal: Do not empty into drains. Remove excess material from tools before cleaning. Some local authorities have special facilities for the disposal of waste liquids. Remove lid and allow residue to dry in a safe place prior to disposal of empty containers.

Sizes Available:

2.5kg